

6.0 PARTS LIST

PRELIMINARY ISSUE

PB1

QTY -011	PART NUMBER	DESCRIPTION
X	D066-1004-011	PRIMARY CARGO HOOK
1	D4983-041	HOOK ASSEMBLY
1	D5008-1	MANUAL RELEASE CABLE
1	D5051-1	CYCLIC SWITCH HOUSING
1	D5052-1	CYCLIC ELECTRICAL SWITCH
1	D5066-3	PLACARD (DEPRESS AND PULL)
1	D5066-5	PLACARD (LOAD LIMIT)
1	D5066-7	PLACARD (CARGO RELEASE)
1	D5066-9	PLACARD (CARGO)
1	D5092-1	DOUBLER
1	D5095-1	FUSE HOLDER
2	D5096-1	FUSE
1	D5108-1	RELAY BRACKET
1	D5116-041	WIRING HARNESS
1	M12883/55-01	RELAY BASE
1	M6106/19-017	RELAY
1	MS21042L06	STEEL LOCK NUT
2	MS21919WDG5	CLAMPS
2	MS24665-151	COTTER PIN
1	MS26574-20	20 AMP CIRCUIT BREAKER
4	MS27039-806	SCREW
2	MS27039-0810	SCREW
1	MS35206-227	SCREW
1	MS35489-149	GROMMET
2	NAS43DD3-16N	STANDOFF

• COPYRIGHT © 2014 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **B**

Date: 14.06.20